

Topic:	Jaguar XF (X250) Driving Contols
Who To:	All Personnel
Summary:	How to operate the Drive Selector on the Jaguar XF

Jaguar Drive Selector

When the engine is started, the selector will rise from the centre console.

Gearshift interlock

The brake pedal must be depressed before the selector can be moved from the Park position.



Select P before switching off the engine. However, if the engine is switched off with Reverse, Drive or Sport selected, the selector will automatically return to P while retracting.

If the engine is switched off with Neutral selected, automatic selection of P is delayed for 10 minutes. DO NOT use this feature for towing purposes.

Manual gear changes



The steering wheel paddles allow manual gear changing with either D or S selected.

- To shift down, briefly pull the - paddle.
- To shift up, briefly pull the + paddle.

When the paddles are used in D, gear selection will revert to automatic if use of the paddles is not maintained. Automatic operation can also be achieved by holding the + paddle for two seconds.

With S selected, continuous manual operation is initiated if the paddles are used. It will only be cancelled by holding the + paddle for two seconds, or by selecting D.

ISSUE LEVEL	DATE : 04/10/07	ORIGINATOR : CHRIS MCLOUGHLIN	DEPARTMENT : TRANSPORT QUALITY
-------------	-----------------	-------------------------------	--------------------------------

Number of Single Point Lesson:

1