















Flash Control Logistic method : case of a vehicle with Direction on the left

Phase	Zone to be controlled	Verification	Position	Time	Pictures
1	Administrative (preparation of vehicle)	Agreement chassis number/ documents. Check the windscreen or the bodywork - Agreement of equipment/documents. For reception clerk VN - vehicle/an equipment list	In front of the vehicle	20"	
2	Facing the Front : Bonnet – Driver & Passenger Compartment, Windscreen, Headlights, Radiator Grille, Front Shield	Damage to panels, paint Damage to Optics lights, lenses glass	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres	10"	
3	Facing the Left Side of the vehicle	Damage to panels, paint	Leaning forward, squatting/crouching at ¼ rear facing the vehicle – between 1 and 3 metres	7"	
	LHF panel	Damage to panels, paint	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres		
	Tyre and Rim	Check that the tyre is not under inflated and the presence of the valve cap	Leaning forward or squatting/crouching		
4	LHF Door	Damage to panels, paint, equipments	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres	5"	
		Existence of the foam of the door protection			
5	LHF Interior	Check the cleanliness of trims, footwell, carpet, seat coverings, etc	Leaning forward out the vehicle. Door opened	10"	
	Keys and Badges	Presence of the double of the keys			
	Equipements	With the aid of a fiche/Spec.list if existant) check the presence of the equipment/accessories			
	Protections	Check and replace if necessary, the protective floor and seat coverings			
6	LHR Door	Check appearance and damage/degradation - Exterior Panels, Paint and Equipment	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres	5"	
7	Tyre and Rim	Check that the tyre is not under inflated and the presence of the valve cap	Leaning forward or squatting/crouching	7"	
	LHR Wing	Damage to panels, paint	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres		
	Facing the Left Side of the vehicle, costude and roof	Damage to panels, paint, equipments	Leaning forward, squatting/crouching at ¼ rear facing the vehicle – between 1 and 3 metres		
8	Facing the rear : Tailgate – Boot Lid – Rear Screen – Rear Shield, Light	Damage to panels, paint, equipments - Existence of the foam of the door protection	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres	10"	
9	Rear Boot Interior	Check appearance (damage, dirty marks, discolouration) - Check presence of the spare wheel - Check presence of all items specified on specification list for the vehicle (Jack, wheelbrace, Towing Ring, first aid kit, Hub caps, aerial, Locking Wheel nuts, etc	Leaned outside towards the interior of the vehicle. Door opened	20"	
10	Face the RH Side, custode and roof	Damage to panels, paint, equipments - Check the presence of the fuel reservoir cap	Leaning forward, squatting/crouching at ¼ rear facing the vehicle – between 1 and 3 metres	7"	
	RHR Wing	Damage to panels, paint	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres		
	Tyre and Rim	Check that the tyre is not under inflated and the presence of the valve cap	Leaning forward, squatting/crouching in front of the vehicle		
11	RHR Door	Damage to panels, paint, equipments	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres	5"	
12	RHF Door	Damage to panels, paint, equipments	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres	5"	
13	RHF Interior	Check the concordance of the door trims and front and back of seat coverings - Check cleanliness of trims, Carpet, seat, Steering wheel, gear lever, etc	Leaned outside towards the interior of the vehicle. Door opened	10"	
14	Tyre and Rim	Check that the tyre is not under inflated and the presence of the valve cap	Leaning forward, squatting/crouching in front of the vehicle	7"	
	RHF Panel	Damage to panels, paint	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres		
	Facing the Right Side of the vehicle and roof	Damage to panels, paint	Leaning forward, squatting/crouching in front of the vehicle – between 1 and 3 metres		